

# MAXIMUS-3

---

10A/X & HARD ROCK RUBICON

NATO Jerry Can Mount

## INSTALLATION GUIDES

PLEASE MAKE SURE YOU READ AND UNDERSTAND THE ENTIRE INSTALLATION GUIDE BEFORE YOU START. WE EXPECT YOU TO HAVE BASIC MECHANICAL ABILITIES TO PERFORM THIS INSTALLATION.

WE RECOMMEND THAT YOU SEPARATE AND IDENTIFY ALL THE PARTS AND HARDWARE KITS YOU RECEIVED WITH YOUR SHIPMENT BEFORE YOU PROCEED TO DISASSEMBLE YOUR JEEP.

---

### **Parts List:**

### **Qty**

M8 x 16 Button Socket  
8mm x 15 Washer

4  
4



## INSTALLATION STEPS

### **(1)- INSTALL AS SHOWN IN THE PICTURES BELOW:**

Install Nato Jerry Can on the top and bottom of the tire carrier as shown in pictures below. Make sure that Nato Jerry Can is secured before driving.



Your installation is complete. If you have questions regarding this installation please contact us at [info@maximus-3.com](mailto:info@maximus-3.com) or call 248 821 6654.