

MAXIMUS-3

10A/X & HARD ROCK RUBICON JL HOOK ANCHOR OR FAIRLEAD CENTERING PLATE INSTALLATION GUIDES

PLEASE MAKE SURE YOU READ AND UNDERSTAND THE ENTIRE INSTALLATION GUIDE BEFORE YOU START. WE EXPECT YOU TO HAVE BASIC MECHANICAL ABILITIES TO PERFORM THIS INSTALLATION.

WE RECOMMEND THAT YOU SEPARATE AND IDENTIFY ALL THE PARTS AND HARDWARE KITS YOU RECEIVED WITH YOUR SHIPMENT BEFORE YOU PROCEED TO DISASSEMBLE YOUR BUMPER.

Parts List:

Fairlead Centering Plate
or Hook Anchor

Qty

1

Hardware Component List:

M8 x 25 - Black Stainless Steel
M8 Flanged nuts – Zinc Plated

Qty

4

4

Tools Required:

- Basic hand tools
- Allen Wrench #5
- Box wrench 13mm

PREPARE BUMPER

(1) REMOVE PLASTIC FAIRLEAD TRIM PIECE: Press retainer clips, pop out of bumper

(2) BOLT FAIRLEAD PLATE (OR WINCH HOOK ANCHOR) TO THE BUMPER:

With the supplied hardware (four M8 bolts & four M8 flange nuts) Use #5 Allen Key. Line-up the fairlead holes on the plate and bumper

(3) BOLT FAIRLEAD TO FAIRLEAD PLATE (OR WINCH HOOK ANCHOR) & BUMPER:

This hardware is supplied by the manufacturer of your fairlead or winch.

