

MAXIMUS-3



10A/X & HARD ROCK RUBICON

JW SPEAKER FOG LIGHT BRACKETS

(Fits JWS 6145 Model & Rigid D-Series Brackets)

THIS INSTALLATION REQUIRES MINOR MODIFICATION TO YOUR LIGHT TABS

INSTALLATION GUIDES

PLEASE MAKE SURE YOU READ AND UNDERSTAND THE ENTIRE INSTALLATION GUIDE BEFORE YOU START. WE EXPECT YOU TO HAVE BASIC MECHANICAL ABILITIES TO PERFORM THIS INSTALLATION.

WE RECOMMEND THAT YOU SEPARATE AND IDENTIFY ALL THE PARTS AND HARDWARE KITS YOU RECEIVED WITH YOUR SHIPMENT BEFORE YOU PROCEED TO DISASSEMBLE YOUR BUMPER.

Component List:

Maximus-3 JW Speaker Fog Light Brackets	2
M4 Stainless Steel Screws	4

Tools Required:

Allen Keys
Torx Key T30



INSTALLATION STEPS:

(A)- REMOVE THE FACTORY FOG LIGHTS

Using torx T30 bit, unbolt two bolts from rear-side of bumper fog light holes. Keep these bolts as they will be used in reassembly. Be sure to disconnect electrical connections and maintain connectors for reassembly.

(B)- ASSEMBLE JW SPEAKER FOG LIGHTS TO MAXIMUS-3 BRACKETS

Using an Allen Key, bolt the Maximus-3 Fog Light Bracket to the fog light using the M4 Stainless Steel Screws supplied.

10/15/2015
6654

2295 N. Opdyke Rd, Suite E, Auburn Hills, MI 48326

P: (248) 821

MAXIMUS-3.COM