

# MAXIMUS-3



10A/X & HARD ROCK RUBICON

## Front Hi-Lift Jack Mount

### INSTALLATION GUIDES

PLEASE MAKE SURE YOU READ AND UNDERSTAND THE ENTIRE INSTALLATION GUIDE BEFORE YOU START. WE EXPECT YOU TO HAVE BASIC MECHANICAL ABILITIES TO PERFORM THIS INSTALLATION.

WE RECOMMEND THAT YOU SEPARATE AND IDENTIFY ALL THE PARTS AND HARDWARE KITS YOU RECEIVED WITH YOUR SHIPMENT BEFORE YOU PROCEED TO DISASSEMBLE YOUR BUMPER.

#### Parts List:

Front Mount Hi-Lift Jack Mount Bracket  
M8x30 Button Head Stainless Steel  
M8 Stainless Steel Washers  
M8 Flange Nuts

#### Qty

1  
4  
4  
4

#### Tools Required:

Allen Wrench Set

### INSTALLATION STEPS

#### (1)- INSTALL AS SHOWN IN THE PICTURES BELOW:

Install Hi-Lift Jack mounts on the front and top of the bumper as shown below.  
Make sure that Hi-Lift Jack is secured before driving.



Your installation is complete. If you have questions regarding this installation please contact us at [info@maximus-3.com](mailto:info@maximus-3.com) or call 248 821 6654.