

MAXIMUS-3



Maximus-3 Max Glide Fairlead

INSTALLATION GUIDES

PLEASE MAKE SURE YOU READ AND UNDERSTAND THE ENTIRE INSTALLATION GUIDE BEFORE YOU START. WE EXPECT YOU TO HAVE BASIC MECHANICAL ABILITIES TO PERFORM THIS INSTALLATION.

WE RECOMMEND THAT YOU SEPARATE AND IDENTIFY ALL THE PARTS AND HARDWARE KITS YOU RECEIVED WITH YOUR SHIPMENT BEFORE YOU PROCEED TO DISASSEMBLE YOUR BUMPER.

Component List:

Maximus-3 FairLead
M10 Button Sockets
M10 Washers
M10 Nuts

Qty

1
2
2
2

Tools Required:

Basic Hand Tools



INSTALLATION:

Step 1: Hold fairlead up to mounting point, aligning the mounting holes with the holes on your bumper/plate.

Step 2: Slide the bolt and washers through the fairlead and mounting holes.

Step 3: Attach the nuts from behind.

Step 4: Make sure the Fairlead is centered then tighten down.



Your installation is complete. If you have questions regarding this installation, please contact us at info@maximus-3.com or call 248 821 6654.