

MAXIMUS-3



JL RUBICON BUMPER ACCESSORIES Dually Auxiliary Light Bracket

INSTALLATION GUIDES

PLEASE MAKE SURE YOU READ AND UNDERSTAND THE ENTIRE INSTALLATION GUIDE BEFORE YOU START. WE EXPECT YOU TO HAVE BASIC MECHANICAL ABILITIES TO PERFORM THIS INSTALLATION.

WE RECOMMEND THAT YOU SEPARATE AND IDENTIFY ALL THE PARTS AND HARDWARE KITS YOU RECEIVED WITH YOUR SHIPMENT BEFORE YOU PROCEED TO DISASSEMBLE YOUR BUMPER.

Component List:

JL Rubicon Auxiliary Light Bracket
Hardware Kit

Qty

1
1



Tools Required:

T 45 Torx bit and ratchet

INSTALLATION STEPS:

1. Using T45 torx bit, remove the 3 factory front bolts/screws from the bumper.
2. Align your Maximus-3 Auxiliary Light Bracket to the holes on the bumper and bolt down using the factory bolts or the supplied hardware. Refer to picture below.
3. Bolt your Lights to the bracket as shown and route the wiring under the grill and the hood as desired, then connect following wiring instructions supplied with your lights.



Your installation is complete. If you have questions regarding this installation please contact us at info@maximus-3.com or call 248 821 6654.