# $\frac{MAXIMUS-3}{\star\star\star}$

## JL WRANGLER

# SATELLITE ANTENNA RELOCATION BRACKET

# **INSTALLATION GUIDE**

PLEASE MAKE SURE YOU READ AND UNDERSTAND THE ENTIRE INSTALLATION GUIDE BEFORE YOU START. WE EXPECT YOU TO HAVE BASIC MECHANICAL ABILITIES TO PERFORM THIS INSTALLATION.

WE RECOMMEND THAT YOU SEPARATE AND IDENTIFY ALL THE PARTS AND HARDWARE KITS YOU RECEIVED WITH YOUR SHIPMENT BEFORE YOU PROCEED TO DISASSEMBLE YOUR JEEP.

Parts List:	
Relocation Bracket Hardware Kit	

**Qty** 1 1 **Tools Required:** 

10mm Socket Socket Wrench T-25 Torx Bit

# **INSTALLATION STEPS**

### (1)- REMOVE SOUNDBAR & TRIM-PIECES

- A. Remove the driver's side "Freedom Panel"
- B. Remove all T-25 torx bolts on plastic trim pieces, then pull to release clips.
- C. Remove all T-25 torx bolts on Soundbar, then pull to release clips.
- D. Unclip all electrical harnesses from soundbar and antennas (4x harnesses in our JL Rubicon)
- E. Remove the (6) soundbar bolts, using a 10 mm socket wrench



P: (248) 821 6654

### MAXIMUS-3.COM

#### (2)- RELOCATE SATELLITE ANTENNA:

- A. Un-bolt Satellite Antenna and separate it's wire from other wires by removing the tape holding them together.
- B. Free enough wire to relocate the satellite antenna to front windshield frame (near driver's side sun visor)
- C. Install the Antenna on the Maximus-3 Relocation Bracket using factory 4-prong clip and provided M6 fastener.

D. Install the Antenna Relocation Bracket to the hole on the windshield frame use the provided M6 bolt, washer, and flange nut



(3)- REINSTALL SOUNDBAR & TRIM-PIECES

soundbar.

A. Reverse the processes from step (1) to reinstall: soundbar, plastic trim-pieces, and freedom panel(s)B. Be sure to plug-in all electric connectors on the





Your installation is complete. If you have questions regarding this installation, please contact us at <u>sales@maximus-3.com</u> or call 248 821 6654.

**MAXIMUS-3.COM**