



## 10A/X RUBICON

*(Low Mount License Plate Bracket)*

### INSTALLATION GUIDES

PLEASE MAKE SURE YOU READ AND UNDERSTAND THE ENTIRE INSTALLATION GUIDE BEFORE YOU START. WE EXPECT YOU TO HAVE BASIC MECHANICAL ABILITIES TO PERFORM THIS INSTALLATION.

WE RECOMMEND THAT YOU SEPARATE AND IDENTIFY ALL THE PARTS AND HARDWARE KITS YOU RECEIVED WITH YOUR SHIPMENT BEFORE YOU PROCEED TO DISASSEMBLE YOUR JEEP.

#### Component List:

|                                       |   |
|---------------------------------------|---|
| License Plate Bracket                 | 1 |
| License Plate Frame                   | 1 |
| M6 Truss Head Bolts – Stainless Steel | 4 |
| M6 Thumb Screws – Zinc Plated         | 2 |

#### Tools Required:

Metric Allen Keys  
Your Basic Hand Tools

#### Installation

**Use an M15 socket/wrench to remove the front 3 factory bolts from the skid plate. Align the bracket to the corresponding holes and fasten it using the same factory bolts. (see picture below for reference)**

Using an Allen key pre-assemble your license plate to the Maximus-3 license plate frame using the M6 Stainless steel screws provided.

Mount your license plate and frame assembly to the bracket using the provided thumb screws or the remaining M6 stainless screws.



**Your installation is complete. If you have any questions regarding this installation, please contact us at [Customerservice@maximus-3.com](mailto:Customerservice@maximus-3.com) or call (248) 821-6654**