

MAXIMUS-3



UNIVERSAL WINCH HOOK ANCHOR

(For use with Aluminum Hawse Fairlead with Synthetic Rope/Line)

THIS INSTALLATION DOES NOT REQUIRE ANY DRILLING OR CUTTING

INSTALLATION GUIDES

PLEASE MAKE SURE YOU READ AND UNDERSTAND THE ENTIRE INSTALLATION GUIDE BEFORE YOU START. WE EXPECT YOU TO HAVE BASIC MECHANICAL ABILITIES TO PERFORM THIS INSTALLATION.

WE RECOMMEND THAT YOU SEPARATE AND IDENTIFY ALL THE PARTS AND HARDWARE KITS YOU RECEIVED WITH YOUR SHIPMENT BEFORE YOU PROCEED TO DISASSEMBLE YOUR TRUCK.

Component List: Maximus-3 Winch Hook Anchor



INSTALLATION STEPS:

(A)- REMOVE THE FACTORY BUMPER END CAPS

Line up the holes on Maximus-3 Winch Hook Anchor to your Hawse Fairlead and bolt to the bumper as shown above – The Hook Anchor comes between the Fairlead and the bumper or your mount plate.



Your installation is complete. If you have questions regarding this installation please contact us at info@maximus-3.com or call 248 821 6654.