

MAXIMUS-3

JK/10A/X & HARD ROCK RUBICON

REAR TOW LOOPS (Rock Slide/Wear Plates)

INSTALLATION GUIDES

PLEASE MAKE SURE YOU READ AND UNDERSTAND THE ENTIRE INSTALLATION GUIDE BEFORE YOU START. WE EXPECT YOU TO HAVE BASIC MECHANICAL ABILITIES TO PERFORM THIS INSTALLATION.

WE RECOMMEND THAT YOU SEPARATE AND IDENTIFY ALL THE PARTS AND HARDWARE KITS YOU RECEIVED WITH YOUR SHIPMENT BEFORE YOU PROCEED TO DISASSEMBLE YOUR JEEP.

Parts List:

Qty

Tow Loops LHS/RHS
5/8" Grade 8 Bolts
Flat Washers

2
4
4

Tools Required:

Basic Hand Tools
Wrench/spanner and Sockets



INSTALLATION STEPS

(1)- REMOVE THE REAR BUMPER

(2)- REMOVE YOUR FACTORY TOW LOOPS IF ANY

(3)- INSTALL YOUR MAXIMUS-3 TOW LOOPS:

- Insert the Nut Plate inside the chassis frame, align to mounting holes and bolt your Maximus-3 Tow Loop on the outside of the frame using the 5/8" Hex Bolts and Washers as shown below.
- Tighten the bolts - (torque to 115 Ft.Lb.)



(4)- REPEAT THE SAME ON THE OTHER SIDE

(5)- RE-ASSEMBLE YOUR REAR BUMPER



Your installation is complete. If you have questions regarding this installation please contact us at info@maximus-3.com or call 248 821 6654.